



OCCASION

This publication has been made available to the public on the occasion of the 50th anniversary of the United Nations Industrial Development Organisation.



DISCLAIMER

This document has been produced without formal United Nations editing. The designations employed and the presentation of the material in this document do not imply the expression of any opinion whatsoever on the part of the Secretariat of the United Nations Industrial Development Organization (UNIDO) concerning the legal status of any country, territory, city or area or of its authorities, or concerning the delimitation of its frontiers or boundaries, or its economic system or degree of development. Designations such as "developed", "industrialized" and "developing" are intended for statistical convenience and do not necessarily express a judgment about the stage reached by a particular country or area in the development process. Mention of firm names or commercial products does not constitute an endorsement by UNIDO.

FAIR USE POLICY

Any part of this publication may be quoted and referenced for educational and research purposes without additional permission from UNIDO. However, those who make use of quoting and referencing this publication are requested to follow the Fair Use Policy of giving due credit to UNIDO.

CONTACT

Please contact <u>publications@unido.org</u> for further information concerning UNIDO publications.

For more information about UNIDO, please visit us at www.unido.org

22238

OFFICE:

No. 201

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal

Final Report (Page 1)

ICRC
Industrial Control
Research Center

REPORT

CONVERSION OF

YAZD ARG METAL Co.

HOT CHAMBER

FINAL REPORT

Contract No. 99/131P

UNIDO's PROJECT No. MP/IRA/98/087

30 Oct 99

OFFICE:

No. 201

Mahestan Bld. Enghelab Sqr.

TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal

Final Report (Page 2)



TABLE OF CONTENTS

- 1-SYNOPSIS
- 2-INTRODUCTION
- 3-ICRC HOT CHAMBER CHARACTERISTICS
- 4- PLANT HOT CHAMBER, TECHNICAL CHARACTERISTICS
- 5- CENTER HOT CHAMBER TECHNICAL CHARACTERISTICS
- **6-ACTIVITIES**
- 7 SUPPLY PARTS AND MATERIALS
- **8-CONCLUSION**
- 9-RECOMMENDATION
- **10-ATTACHMENTS**

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 3)



SYNOPSIS

Under supreme supervision of UNIDO the CFC phase project has been implemented in Iran to phase out 100 % ODS in some Iranian White Industries

The project No. MP/IRA/98/087 has been nominated to Islamic Republic of Iran for the Multilateral Fund for the implementation of The Montreal Protocol Financing.

The project was approved by Montreal Protocol Multilateral Fund executive committee. The project was actually started in November 1994, but the implementation of the project has been already started from January 1994, by recommendation of Montreal Protocol and request of Government of Islamic Republic of Iran, the refrigerant R134a was finally approved and selected by UNIDO as an alternative for refrigerant R12.

Yazd Arg Metal Co. As a home appliance manufacturer in Iran the main activities of Yazd Arg Metal Co., is producing refrigerators and freezers,

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 4)



INTRODUCTION

According to UNIDO contract No. 99/131P with Industrial Control Research Center Co. (ICRC) the existing *Yazd Arg Metal Co.* hot chambers facilities shall be converted and modified to phase out CFC-12 and suitable for R134a refrigerant to perform functionality and performance test of converted refrigerators and complying with ISO standards 7173, 8187, and 5155.

1 This proposal has been prepared based on the requirements of Islamic Republic of Iran indicated in the country program no *UNEP/OZL.PRO/EX COM/10/24* dated 27 May 1993 prepared by UNDP.

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 5)



- 2 The CFC phase out project in Yazd Arg Metal Co. will enable Yazd Arg Metal Co. to convert the existing production line facilities and existing hot chambers into Non CFC production line, using R134a refrigerant.
- 3 The converted Hot Chamber Installations will provide more than 20 data points in the refrigeration circuit this means more information and the ability of analyzing refrigeration system and new refrigerant effect.
- 4 The reconstructed Hot Chamber will be able to check and test 2 refrigerator and/or ref.-freezers units at the same time. The same equipment and data processing system, as will be used at plant test room will be installed in this chamber.
- 5 The immediate effect of this project at Yazd Arg Metal Co. is to perform all required check and tests, suitable for Refrigerator & Freezers using Ozone Friendly Gases. The existing test facilities in Yazd Arg Metal Co. are not adequate for check and testing, converted ref. and freezer units, in addition to that the hot rooms are not able to perform Energy Consumption and Optimization Program.

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 6)



ICRC Hot Chamber Characteristics

In order to convert *Yazd Arg Metal Co.* hot rooms facilities , ICRC shall provide following services:

- Supply of new equipment.
- Redesign of old equipment
- Delivery of technical drawings and software.
- Installation and commissioning.
- Start-up of the equipment and the technology.
- On-the-job training of the plant personnel.

With respect to **ISO** standards test requirements, and for the purpose of functionality and performance tests of the new redesigned Refrigerator and Ref.-Freezers using R134a refrigerants. The existing hot room in *Yazd Arg Metal Co.* is being converted and equipped in such a way to enable *Yazd Arg Metal Co.* to check and test at least one different models of refrigerators and freezers at ambient temperature 32 to 43 degree centigrade at one hot room chambers. In addition to these services is providing. But the hot room is capable to test eight refrigerators and freezers in case of adding more transducers and sensors in the main panel in the hot room:

- a) Procurement of new test measurement and data processing equipment.
- b) Redesign and rebuilding of presently used equipment and installation.
- c) Installation, commissioning, trial operation, start-up and on-the-job training

Mahestan Bld. Enghelab Sqr.

TEHRAN IRAN

Tel. 00 98 21 6432854

Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 7)



YAZD ARG METAL HOT CHAMBER TECHNICAL SPECIFICATION

As previously mentioned, Yazd Arg Metal Co.'s plant is producing 50 refrigerator daily. And subsequently the hot chamber should have been able to cover plant daily test requirement as well as other activities. Therefore, the converted hot chamber should respond to all test requirement and be able to meet ISO standards numbers 7371, 5155, 8187 as set forth in the contract and IJISI, Iranian standards numbers 254, 2482, 2818. The plant hot chamber technical specification are as follows:

- Hot Chamber Dimension about 3 mt. by 3 mt.
- Refrigerator test ability simultaneously, 2 units and ability to test 6 sample out of the room
- Ability to perform following operational tests and report:
 - 1 Pull down test.
 - 2 Continuous run test.
 - 3 Cyclic run test.
 - 4 Ice Freeze test.
 - 5 Energy consumption test

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 8)



- 20 Measuring points, including. (for each applia.)
 - 1 Humidity, one point for one hot room.
 - 2 Compressor Power, 2 point
 - 3 Motor current, 2 point.
 - 4 Supply Voltage, 2 point.
 - 5 Hot chamber air temperature reading, one point.

160 points for eight models in case of improving the system by spending very low costs.

- Computerized graphical diagram of the refrigerator performance data sheet.
- Test measurement tolerance for temperature reading 0.3 degree centigrade.
- Computerized data processing system.
- Full color test sheet system reporting.

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 9)



- On screen and data reporting system ability with following characteristics;
 - 1 Test number.
 - 2 Product name.
 - 3 Product model
 - 4 Product internal volume
 - 5 Compressor name
 - 6 Compressor model
 - 7 Compressor cooling capacity
 - 8 Compressor current
 - 9 Thermostat setting
 - 10 Thermostat type.
 - 11 Total test running time.
 - 12 Ambient temperature.
 - 13 Voltage rating
 - 14 Working percentage

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 10)



- 15 Evaporator mean air temperature
- 16 Cabin mean temperature
- 17 Evaporator bulb temperature
- 18 Crisper temperature.
- 19 Actual compressor running time
- 20 Energy consumption
- 21 Compressor motor winding temperature
- 22 Compressor shell temperature.
- 23 Compressor discharge temperature.
- 24 Condenser inlet temperature.
- 25 Condenser out let temperature.
- 26 Condenser mid temperature
- 27 Evaporator inlet temperature
- 28 Evaporator outlet temperature.
- 29 Freezing temperature.
- 30 Refrigeration system condition display.

Mahestan Bld. Enghelab Sqr.

TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 11)



ACTIVITIES

The following activities were accomplished so far toward achievement of the contract requirement as set forth by UNIDO and the counterpart.

- 1 Planning for;
 - a) Hot chambers system management.
 - b) Hot chambers graphic display management.
 - c) Hot chambers calibration setting parameters.
 - d) Hot chambers test standards management
- 2 Preparing material requirement list.
- 3 Component and material supply source evaluation.
- 4 Technical data collecting.
- 5 Engineering drawing for electronic and electrical system
- 6 Hot chamber design review.

Mahestan Bld. Enghelab Sqr.


TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 12)



- 7 Data processing software planning.
- 8 Data processing hardware planning.
- 9 Thermal amplification electronic cart design
- 10 Preparation of timer 1 flow chart..
- 11 Initial test of data loggers electronic cart.
- 12 Initial connection of data loggers to the computers.
 - 3 Interface electronic cart design for PC and operating system.
- 4 RTX3 electronic diagram design.
- 5 RTX electronic diagram design.
- 6 UNIDO, CRC 386 design.



Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 13)



20 - Visits and coordination;

20/1:

- -Visiting plant One day, One engineer, one time.
- -Visiting and coordinating with UNDP office .
- -Technical negotiation with *Yazd Arg Metal Co.* engineers and hot chamber in order to coordinate activities.
- -Advising for the necessary modification on the Room .

20/2:

- -Visiting plant 3 days, 5 engineer and Technician, one time.
- -Installation Electronic Panel
- -Installation Electrical Panel
- -Completing The Room
- -Starting Test
- -Controlling Condition Of the Room
- -Testing 2 Samples for Energy Consumption
- -Testing 2 Samples for Performance Test
- -Testing 2 Samples for Fume Quality
- -Teaching the technical Test

Mahestan Bld. Enghelab Sqr.

TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Yazd Arg Metal Final Report (Page 14)



- -Visiting and coordinating with UNDP office.
- -Technical negotiation with **Yazd Arg Metal Co.** engineers and hot chamber in order to coordinate activities.
- -Advising for the necessary modification on the Samples .

21 - Soft Ware:

- -data gathering
- -calibrating
- -printing
- -editing
- -humidi curving
- self checking

All software are installed and Started

> Mahestan Bld. Enghelab Sqr. **TEHRAN IRAN**

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Final Report (Page 15) Yazd Arg Metal



SUPPLY PARTS AND MATERIALS

In order to fabricate components and electronic kits following material and parts have been purchased so far.

- 1 Semiconductor sensors for measuring temperature from 30 to + 110 degree centigrade. 32 each
- 2 Electronic humidity measurement sensor 1 each
- 3 Electronic data logger cart for temperature measurement 2 each
- 4 Electronic data logger cart for humidity Calibration 1 each
- 5 ADC912 Converter IC for system conversion management.
- 6 Electronic parts consist of resistor. IC, capacitor, and diode.
- 7 Main Electronic Data Log
- 8- (2*24) Electronic Sensors for Thermal Measuring
- 9- (2*4) Electronic Sensors for Thermal Measuring of Condenser
- 10-Heater Controller contractors

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Final Report (Page 16)



Dim Black, Blue, Green

Dim Cyan, red, Magenta, YELLOW

Dim gray, L_Blue, L_Green

Dim L_cyan, L_red, L_Magenta, L_yellow

Dim prn_color As Integer 'False=Black & White ; True=Color

Dim printcolor As Integer

Dim Y, Repstr\$, Rot_Txt_no%

Dim printerdrawwidth As Integer

Dim offset, PageNo

Dim Lb Tmp As Label

Dim FirstKey

Dim Rec Max%

Dim SegEn

Dim ActiveFrame As Integer
Dim ActiveLabel As Integer
Dim Seg_n As Integer

Dim PrnPageNo As Integer Dim ActivePage As Integer

Dim sl%, st%, sw%, sh%, dw% Dim a30 As String * 30

Dim rr() 'Extracted Results

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854

Fax 00 98 21 6420759

Final Report (Page 17)



```
Sub cmd_click (Index As Integer)
    Select Case Index
        Case 0
                                       'print
            screen.MousePointer = 11
            Cmd(0). Enabled = False
            Cmd(1). Enabled = False
            DoEvents
            Call Print All
            Call Save Spec
            screen.MousePointer = 0
            Cmd(0).Enabled = True
            Cmd(1).Enabled = True
            'Unload Me
        Case 1
                                      'Save
            nn = Variable("Prnt", "Write")
            nn = Variable("Prnt", "Read")
        Case 2
                                      'cancel
            Unload Me
        Case 3
            Me.Hide
            Paper.Show
    End Select
    Exit Sub
End Sub
Sub Color_chk_Click (Value As Integer)
   ' If color chk. Value = False Then
         prn color = False
```

OFFICE: No. 201
Mahestan Bld.
Enghelab Sqr.
TEHRAN IRAN
Tel. 00 98 21 6432854

Fax 00 98 21 6420759

Final Report (Page 18)



```
color = 0
      Black = color
      Blue = color
      Green = color
      Cyan = color
      red = color
      Magenta = color
      YELLOW = color
      gray = color
      L Blue = color
      L Green = color
      L cyan = color
      L red = color
      L Magenta = color
      L yellow = color
' Else
     prn color = True
     Black = QBColor(0)
     Blue = QBColor(1)
     Green = QBColor(2)
     Cyan = QBColor(3)
     red = QBColor(4)
     Magenta = QBColor(5)
     YELLOW = QBColor(6)
     gray = QBColor(8)
     L Blue = QBColor(9)
     L Green = QBColor(10)
     L cyan = QBColor(11)
     L red = QBColor(12)
     L_Magenta = QBColor(13)
     L yellow = QBColor(14)
' End If
```

End Sub

OFFICE: No. 201
Mahestan Bld.
Enghelab Sqr.
TEHRAN IRAN
Tel. 00 98 21 6432854

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Final Report (Page 19)



```
Sub crv (mode$, Rec1, Rec2)
  Select Case mode$
    Case "prn"
        printer.ForeColor = Black
        printer.FontName = "Arial"
        printer.FontSize = 10
        obj = ActiveObj
        'print x axis
        printer.DrawWidth = 3 * printerdrawwidth
        printer.Line (Rec1, 0)-(Rec2, 0)'axis
        printer.DrawWidth = 1
        printer.DrawStyle = 2'=DOt 3=Dash-Dot 4=Dash Dot Dot
        For i = -300 To 1000 Step 100
            printer.Line (Rec1, i) - (Rec2, i)
        Next i
        rec = zoom(Seg_n).X1
        printer.DrawWidth = 3 * printerdrawwidth
        printer.ForeColor = IIf(prn_color = False, Black,
         zoom(Seg_n).BorderColor)
        printer.Line (rec, -300) - (rec, 1000)
        printer.DrawStyle = 0 'Solid
        printer.DrawWidth = 1 * printerdrawwidth
        printer.CurrentX = rec - RecLb(Seq n).Width / 2
        printer.CurrentY = 1030
        printer.Print RecLb(Seg n).Caption
        n = -1
        R1 = (Rec1 \setminus 10 + 1) * 10
        R2 = (Rec2 \setminus 10) * 10
```

OFFICE: No. 201
Mahestan Bld.
Enghelab Sqr.
TEHRAN IRAN
Tel. 00 98 21 6432854
Fax 00 98 21 6420759



Final Report (Page 20)

```
printer.FontSize = 5
       printer.ForeColor = Black
       For rec = R1 To R2 Step 10
           printer.Line (rec, 10)-(rec, -10), Black
           n = n + 1
           If n \mod 3 = 0 Then
               b$ = Right$("0" & rec \ 60, 2) & ":" & Right$("0" &
        rec Mod 60, 2)
               printer.CurrentX = rec - 2'offset / 13
               printer.CurrentY = -12
               printer.Print b$
           End If
       Next rec
       'graph
       For n = 0 To 1
           For d = 1 To 6
               If curve_Item(n, d) < 50 Then</pre>
                    z = curve_Item(n, d)
                    If curve color(n, d) = 15 Then col = 0 Else col =
        curve color(n, d)
                   printer.ForeColor = IIf(prn color = False, Black,
        QBColor(col))
                    For rec = Rec1 To Rec2 - 1
                       bool1 = grf(26, rec) = 789
                       bool2 = qrf(26, rec + 1) = 789
                        If bool1 And bool2 Then
                            Y1 = grf(z, rec)
                            Y2 = grf(z, rec + 1)
                            printer.Line (rec, Y1)-(rec + 1, Y2)
                       End If
                   Next rec
               End If
            Next d
       Next n
```

OFFICE: No. 201 Mahestan Bld. Enghelab Sqr. TEHRAN IRAN Tel. 00 98 21 6432854

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Final Report (Page 21)



```
Case "grfall"
      On Error Resume Next 'Note: Karim
      obj = ActiveObj
      grafall.Cls
      grafall.DrawMode = 7
                                                   '(7=xor 13=copy)
      RecAll End = UBound(grf, 2) - 1
      If Err = 9 Then
          Rec Max = 0
          Exit Sub
      End If
      Rec Max = RecAll End
      screen.MousePointer = 11
      sw = IIf(RecAll_End < 100, 100, RecAll_End)</pre>
      grafall.ScaleWidth = sw'+ recall end \ 10
      grafall.ScaleLeft = 0
      recall start = 1
      grafall.Line (recall start, 0) - (RecAll End, 0), QBColor(3)
      For n = 0 To 1
      For d = 1 To 6
        If curve Item(n, d) < 50 Then
          z = curve Item(n, d)
          If Hr.lbt(z).Visible = True Then
            grafall.ForeColor = QBColor(curve color(n, d))
            For rec = recall start To RecAll End - 1
              If grf(26, rec) = 789 And grf(26, rec + 1) = 789 Then
                grafall.Line (rec, grf(z, rec))-(rec + 1, grf(z, rec
       + 1))
              End If
            Next rec
          Else
              curve Item(n, d) = 50
              Hr.lbt(z).ForeColor = QBColor(0)
```

Mahestan Bld. Enghelab Sqr. TEHRAN IRAN

Tel. 00 98 21 6432854 Fax 00 98 21 6420759

Final Report (Page 22)



```
End If
      Next d
    Next n
    screen.MousePointer = 0
Case "qrfzoom"
    On Error Resume Next
    obj = ActiveObj
    zoomarea = 30
    zoomarea2 = zoomarea \ 2
    grafzoom.ScaleWidth = zoomarea
    'X = Int(zoom.X1 + .5)
    'If X > Rec Max Then Stop
    grafzoom.ScaleLeft = X - zoomarea2
    Rec Start = IIf(X - zoomarea2 > 0, X - zoomarea2, 0)
    Rec_end = IIf(X + zoomarea2 < Rec_Max, X + zoomarea2, Rec_Max)</pre>
    'Rec Start = Seg(ActiveSeg).Left
    'Rec End = Rec Start + Seg(ActiveSeg).Width
    'grafzoom.ScaleWidth = Seg(ActiveSeg).Width
    'grafzoom.ScaleLeft = Rec Start
    grafzoom.Cls
    grafzoom.DrawMode = 7
                                                 '(7=xor 13=copy)
    grafzoom.Line (Rec Start, 0) - (Rec end, 0), QBColor(3)
    For n = 0 To 1
    For d = 1 To 6
      If curve Item(n, d) < 50 Then
        z = curve Item(n, d)
        If Hr.lbt(z).Visible = True Then
          grafzoom.ForeColor = QBColor(curve color(n, d))
          For rec = Rec Start To Rec end - 1
            If grf(26, rec) = 789 And grf(26, rec + 1) = 789 Then
              grafzoom.Line (rec, grf(z, rec))-(rec + 1, grf(z,
```

```
OFFICE: No. 201
Mahestan Bld.
Enghelab Sqr.
TEHRAN IRAN
Tel. 00 98 21 6432854
Fax 00 98 21 6420759
```



```
Final Report (Page 23)
```

```
rec + 1))
                End If
              Next rec
            Else
                curve Item(n, d) = 50
                Hr.lbt(z).ForeColor = QBColor(0)
                Hr.lbt(z).BackColor = \&H202020
            End If
            End If
          Next d
        Next n
        screen.MousePointer = 0
        Call ResultsGrf_click
    End Select
End Sub
Sub CrvZoom ()
    On Error Resume Next
    grafzoom.Cls.
    If ActivePage < 1 Then</pre>
        Call ResultsGrf click
        Exit Sub
    End If
   obj = ActiveObj
    zoomarea = 30
    zoomarea2 = zoomarea \ 2
    grafzoom.ScaleWidth = HourPerPage * 60
   grafzoom.ScaleLeft = Seg(ActivePage).Left
   Rec Start = grafzoom.ScaleLeft + 1
```

OFFICE: No. 201 Mahestan Bld. Enghelab Sqr. **TEHRAN IRAN** Tel. 00 98 21 6432854

Fax 00 98 21 6420759

Final Report (Page 24)



```
Rec end = Rec Start + grafzoom.ScaleWidth - 1
  If Rec end > UBound(grf, 2) Then Rec end = UBound(grf, 2)
  grafzoom.Cls
  grafzoom.DrawMode = 7
                                                '(7=xor 13=copy)
  grafzoom.Line (Rec Start, 0) - (Rec_end, 0), QBColor(3)
  For n = 0 To 1
      For d = 1 To 6
          If curve Item(n, d) < 50 Then
              z = curve Item(n, d)
              If Hr.lbt(z).Visible = True Then
                  grafzoom.ForeColor = QBColor(curve color(n, d))
                   If Rec Start < 1 Then Rec Start = 1
                  For rec = Rec Start To Rec end - 1
                       bol1 = (qrf(26, rec) = 789)
                       bol2 = (grf(26, rec + 1) = 789)
                       If boll And bol2 Then
                           Y2 = grf(z, rec + 1)
                           Y1 = grf(z, rec)
                           grafzoom.Line (rec, Y1) - (rec + 1, Y2)
                       End If
                  Next rec
              Else
                   'curve Item(n, d) = 50
                   'hr.lbt(z).ForeColor = QBColor(0)
                   'hr.lbt(z).BackColor = &H202020
              End If
          End If
      Next d
 Next n
 z = Int(zoom(ActivePage).X1)
 zoomzoom.X1 = z
 zoomzoom.X2 = z
 zoomzoom.BorderColor = zoom(ActivePage).BorderColor
 Grfzoom pnl.BackColor = zoomzoom.BorderColor
 a\$ = Right\$(("0" \& z \setminus 60), 2) \& ":" \& Right\$(("0" \& z Mod 60), 2)
 RecLb(ActivePage).Caption = a$
 Call ResultsGrf click
```

